



Instrucciones de uso

Plancha sin cable Rowenta

Descripción general

La plancha sin cable Rowenta está diseñada para ofrecer un planchado cómodo, seguro y eficiente, eliminando la limitación del cable. Funciona mediante una base de carga que mantiene la plancha siempre lista para su uso.

1. Preparación

- Coloque la plancha sobre su base de carga.
- Asegúrese de que el depósito de agua esté lleno hasta el nivel máximo.
- Conecte la base a la corriente eléctrica.

2. Calentamiento

- Espere a que el indicador luminoso señale que la plancha está lista para su uso.
- La plancha se calienta automáticamente cada vez que se coloca sobre la base.

3. Uso

- Retire la plancha de la base y planche con normalidad.
- Cuando note una bajada de temperatura, vuelva a colocarla unos segundos en la base.
- Utilice siempre la plancha en posición horizontal y sobre tejidos adecuados.

4. Seguridad

- No deje la plancha caliente sin vigilancia.
- Evite tocar la suela mientras esté caliente.
- Manténgala fuera del alcance de los niños.
- Antes de guardarla en el armario, asegúrese de que la plancha esté completamente fría, evitando así daños, sobrecalentamientos o riesgos innecesarios.

Instructions for use

Rowenta Cordless Iron

General description

The Rowenta cordless iron is designed to provide comfortable, safe and efficient ironing, eliminating the restriction of a power cord. It operates with a charging base that keeps the iron ready for use at all times.

1. Preparation

- Place the iron on its charging base.
- Make sure the water tank is filled up to the maximum level.
- Plug the charging base into the power supply.

2. Heating

- Wait until the indicator light shows that the iron is ready for use.
- The iron automatically reheats each time it is placed on the base.

3. Use

- Remove the iron from the base and iron as usual.
- When temperature decreases, place it back on the base for a few seconds.
- Always use the iron horizontally on suitable fabrics.

4. Safety

- Do not leave the hot iron unattended.
- Avoid touching the soleplate while it is hot.
- Keep out of reach of children.
- Before storing the iron in the wardrobe, make sure it has completely cooled down to avoid damage, overheating or unnecessary risks.