



Instrucciones de Uso – Plancha Vertical de Vapor

ESPAÑOL

Llenado de agua

Añada agua al depósito hasta la línea MAX. Asegúrese de que el aparato esté desenchufado y frío antes de abrir el tapón.

Encendido

Enchufe el dispositivo y mantenga pulsado el botón de encendido durante unos segundos hasta que el indicador se active.

Uso del vapor

Cuelgue la prenda y aplique el vapor de arriba hacia abajo con movimientos lentos.

Apagado

Mantenga pulsado el botón de encendido durante 2 segundos y deje enfriar antes de guardarla.

Seguridad

El vapor está muy caliente. No dirigir hacia la piel y utilizar siempre en posición vertical.

ENGLISH

Water filling

Fill the water tank up to the MAX line. Make sure the device is unplugged and cold.

Power on

Plug in the device and press the power button for a few seconds until it turns on.

Steam use

Hang the garment and move the steamer slowly from top to bottom.

Power off

Press the power button for 2 seconds and allow it to cool before storing.

Safety

Steam is hot and may cause burns. Always use vertically and avoid skin contact.